

blogpost-style, resources, task-1-1

aayushi ♥ e-Yantra Staff Sep '21

**■** Table of contents

### Task 1

Welcome to Task 1 of Strawberry Stacker!!

The task is divided in two sub tasks and a bonus task

- 1. Task 1.1
- 2. Bonus Task
- 3. Task 1.2

### **Task 1.1**

# Overview

In task 1.1, we will be learning the following:

- Basic Image Processing techniques using OpenCV & Python
- · Generating and detecting an ArUco marker
- Finding position and orientation of an ArUco marker.

## **Prerequisites**

First things first, lets get the resources in place, install the necessary packages and go through the learning resources needed to complete the task

### Installations

We assume that you have successfully installed and setup the software and packages as instructed in Task 0.

**Note**: Installation of px4 is not required in task 1, it will be required in further tasks and instructions will be provided in detail. Do not worry if the errors in px4 installations are not solved. If your px4 installations were not completed then create a separate workspace for this task and then follow the instructions. Otherwise you can use the previous catkin workspace.

You need to install the strawberry\_stacker package in your catkin\_ws

Open a new terminal window and type the following command

cd .. catkin build

Make sure your build succeeds without errors, if you face any errors resolve them before proceeding.

### **Learning Resources**

Refer to the learning resources provided here before proceeding.

### Additional tips

ArUco markers have a distinct id and the ArUco library (refer Tutorials) gives us the pixel position of the four corners and the center position of a marker. So this information helps you in finding the position and orientation of a marker. However, there must be a relative scale to measure the orientation of the marker. Orientation of the marker can be measured with respect to horizontal or vertical position. Let's fix the horizontal position as 0° and increasing upto angle 359° in anti-clockwise direction as shown in Figure 1:




Figure 1: ArUco marker detection

Features in the resulting detected image as shown in Figure 2 are:

- Gray dot(125,125,125)(B,G,R) corresponds to top-left of the ArUco marker
- Green dot(0,255,0) corresponds to the top-right of the ArUco marker
- Pink dot(180,105,255) corresponds to the bottom-right of the ArUco marker
- White dot(255,255,255) corresponds to the bottom-left of the ArUco marker
- Red dot(0,0,255) corresponds to the center of the ArUco marker
- Blue line (255,0,0) corresponds to the line joining between the centre of ArUco marker and the mid point of the line joining top-left and top-right. This line gives us the indication of the orientation of the ArUco. The angle between this line with the horizontal axis gives us the required angle
- The upper thick black line indicates the horizontal line. Angle increases till 359° in anticlockwise direction. 55° is the angle between the blue line with this black line.
- Number in Red colour corresponds to the ArUco id
- Number in Green colour corresponds to the Angle of orientation of the ArUco marker
- Watch this video of ArUco detection for understanding the orientation scale better.

### **Problem Statement**

Write Python script for Detecting ArUco markers . The Resulting image must have ArUco markers marked as shown in Figure 1. Hence the resulting image will have ArUco markers with:

- Green dot indicating top-right
- · Pink dot indicating bottom-right
- · White dot indicating bottom-left
- · Red dot indicating center of the ArUco
- · Blue line joining center of ArUco marker and the mid-point between top-left and top-right
- · ArUco id number in RED colour
- Orientation of the ArUco in degrees in GREEN colour

#### **Procedure**

Step 1. Open aryco\_library.py present in scripts folder.

Step 2. Complete the following functions:

## • detect\_ArUco(img)

- Functionality:
  - → Detect id and corners of all the ArUco markers in the test image
- · Arguments:
  - → img: the test image which needs to be tested
- o Return:
  - $\rightarrow$  Detected\_ArUco\_markers: Dictionary in which each id (keys) corresponds to its corners(values).
- Calculate\_orientation\_in\_degrees(Detected\_ArUco\_markers)
  - Functionality:
    - $\rightarrow$  Calculate the orientation of all the ArUco markers (degrees) in the test image relative to the scale as mentioned in Figure 1.
  - o Arguments:
    - → Detected\_ArUco\_markers: the Dictionary returned by detect\_ArUco(img) function
  - o Return:
    - $\rightarrow$  ArUco\_markers\_angles: Dictionary in which keys are the ArUco ids and the values are the corresponding angle of ArUco's in degree
- Mark\_ArUco(img,Detected\_ArUco\_markers,ArUco\_markers\_angles)
  - Functionality:
    - → Mark ArUco markers in the test image as per the instructions given in Figure 1.
  - Arguments:
    - → img: Test image
    - → Detected\_ArUco\_markers: Dictionary returned by detect\_ArUco(img) function
    - → ArUco\_markers\_angles: Dictionary returned by

Calculate\_orientation\_in\_degress(Detected\_ArUco\_markers)

- Return :
  - → img: the resultant image after marking the ArUco's.

Step 3. After completing <code>aruco\_library.py</code>, run the Python script <code>aruco\_detection.py</code> which is present in the same folder as that of <code>aruco\_library.py</code>. Don't change anything in <code>aruco\_detection.py</code>. Once you successfully run <code>aruco\_detection.py</code> you will find two files <code>namely Result\_image\_1.png</code> and <code>Result\_image\_2.png</code> in the folder scripts in your ROS package.

Step 4. Open the result images to ensure that all the attributes that mentioned in Figure1 is marked on all the ArUco markers in the test images.

## **Expected Output**




Figure 2: Expected Output

## **Submission Instructions**

- Copy aruco\_library.py, Result\_image\_1.png and Result\_image\_2.png to a folder named <team\_id>Task1\_1.
- Instructions for uploading the task will be provided on the portal.

# **Bonus Task**

Write a Python script for detecting ArUco markers from a video stream. You can get the video from **here** . You can take help from the aruco\_detection.py script.

# **Expected output**

Your output should look like the video below:

### Note

This topic is closed for responses for a better workflow, please ask your doubts in the **QnA category** using the tag task-1-1. Thanks and all the best.

```
𝚱 URGENT! Error in task 1.1 problem statement
ℰ Task 1 : Getting Started with ArUco and ROS
 \overline{\mathbf{\Phi}}
 ×
  Task 1
  Task 1.1
    Overview
    Prerequisites
        Installations
        Learning Resources
             Additional tips
    Problem Statement
    Expected Output
    Submission Instructions
  Bonus Task
  Note
```

CLOSED ON OCT 18, '21

UNLISTED ON OCT 23, '21